





## Large Screen Hygrometer

Meteorological Instrument

## **■** Details Info

## Features:

On the back with hanging hole, can be hung on the wall stand table

There are four ports on the back of the air flow, flow smoothly in order to more accurately reflect the temperature and humidity

Battery box (2 AAA batteries)

Removable base

Temperature display: 0 ,ÑÉ -50 ,ÑÉ (32 ,Ñâ -122 ,Ñâ)

Temperature display: 20% -99%

Date display: 2001-2099

Memory the maximum and minimum humidity values

12 \ 24-hour clock system

Alarm

Weather display

Resolution: 1 ,ÑÉ

Product Dimensions: 13.6 \* 8 \* 2cm

Screen size: 6.5 \* 4.5cm

Instructions for use:

Short press MODE, see the alarm clock; press MODE, see the calendar

Time setting: Press and hold MODE 3 seconds to enter the time setting, when the hour digits flashing, press UP or DOWN to set the hour, press the MODE button when the minute is flashing, press UP or DOWN to set the minutes.

Alarm clock settings: short press MODE button to view the alarm time, press MODE button for 3 seconds to enter alarm setting mode, when hours are blinking, press the UP or DOWN to set the hour, press the MODE button when the minute is flashing, press UP or DOWN to set the minutes.

Calendar settings: short press MODE button twice to view the calendar, press the MODE button for 3 seconds to enter the calendar setting, when the year number is flashing, press UP or DOWN to set the year, press the MODE button when the month is flashing, press UP or DOWN to set the month, then once a day the number is flashing, press UP or DOWN to set the date.

On / Off Alarm: press the UP button to on / off alarm clock

Max / Min: Short press MAX / MIN button to see the highest temperature and humidity, and then again to view the lowest recorded temperature and humidity.

12/24 hour format: press UP button for 3 seconds to convert a 12/24 hour clock

Temperature display format: Press DOWN key to convert ,ÑÉ / ,Ñâ display

0

Head Office :1600 AVENUE DE LORIMIER BUREAU, 384 MONTRÉAL (QUÉBEC) CANADA H2K3W8 USAOffice:128 W SUFFLOK AVE,CENTRAL ISLIP,11722 N Middle east & Africa Office : warehouse 9 /shed 9, Technology park P.O. Box 54806 RAK FZE , UAE

 $\square$ 

Email Us At:

sales@acculabusa.com middleeast@acculabusa.com

ζ,

Phone Support:

© Copyright 2014 by ACCULAB\_USA - All rights reserved