



Temperature Recorder

| Meteorological Instrument

☰ Details Info

Features:

TR2 Temperature Recorder widely used in food, medicines and fresh goods storage and transportation, and industry compliance with the HACCP system certification, laboratories need to also be used for temperature monitoring sites. Instrument has a stable performance, recording large amount of information, high precision, easy operation, password protection; power failure data is not lost and so on. Widely used in commercial refrigeration equipment operation, HVAC and other industries.

Size	
Panel Size	144 × 144 (mm)
Mounting size	131.5 × 131.5 (mm)
Product size	144 × 144 × 83 (mm)
Technical parameters:	
Temperature range	-40 °C ~ 110 °C

Temperature Accuracy	-10 °C ~ 85 °C, within an accuracy of ± 0.5 °C; the rest of ± 1 °C
Resolution	0.1
alarm temperature difference	0 ~ 20 °C (adjustable)
Alarm output	Buzzer + alarm relay
Recording cycle	1 minute - 24 hours adjustable
Record measurement approach	1 channel
print output	RS232 interface to access the printer output
Power supply	12VAC or 12VDC or 24VDC
start delay	Adjustable from 0 to 6 hours
Alarm Delay	0-90 minutes adjustable
Record capacity	4500 points (MAX)
Alarm relay contact capacity	8A/220VAC

Fault Status:

A, probe failure, over-range limit or over-range limit: ERROR indicator light, fault code flashes EE, buzzer alarm, the alarm relay normally open contact closure alarm sound can not be eliminated.

B, over-temperature alarm: \geq measuring temperature or set temperature + temperature difference between the measured temperature \leq alarm set temperature - temperature difference when the alarm, ALARM indicator light, display flashing, alarm delay, alarm buzzer, alarm relay normally open contacts are closed, press ▼ or alarm temperature is set to 0 2AXX consumer alarm.



Head Office :1600 AVENUE DE LORIMIER BUREAU, 384 MONTRÉAL (QUÉBEC) CANADA H2K3W8 USAOffice:128 W SUFFLOK AVE,CENTRAL ISLIP,11722 N
Middle east & Africa Office : warehouse 9 /shed 9, Technology park P.O. Box 54806 RAK FZE , UAE



Email Us At:

sales@acculabusa.com middleeast@acculabusa.com



Phone Support: