



# Multi-channel noise / vibration measurement and analysis syste

Sound level meter

#### ■ Details Info

### Introduction:

NA70 is a multichannel noise measurement and analytical instrument discretionarily combining noise and vibration measurement. It can achieve the real-time measurer capacity storage capacity, analyse and calculate the time domain and frequency domain of the collected signal. It has much advantages such as multiusage, high precisio time FFT analysis, architectural acoustic measurement.

NA70Multichannel noise / vibration analyzer is composed of computer, package, high speed A / D board, measuring amplification board, charge amplification board, acce

## **Technical Parameters:**

## 1. Noise measurement channels

- (1) Measurement microphone:  $\Phi$ 12.7mm polarization condenser microphone, sensitivity: about 30mV/Pa
- (2) Frequency range: 20Hz-20kHz
- (3) Background noise: direct input short circuit, A weighted less than  $5\mu V$
- (4) Frequency weighting: A, C, Z (linear), can meet the requirement of IEC61672-1: 1
- (5) Anti-mixed filter: built-in, cut-off frequency of 40kHz, 2.5kHz, 630Hz, 200Hz, attenuation -48dB/oct
- (6) Range: 20dB、40dB、60dB、80dB
- (7) AC output: 7V maximum RMS
- (8) Range: 25  $\sim$  140dB with the 30mV/Pa microphone

## 2. Vibration measurement channels

- (1) Sensors: Piezoelectric Accelerometer, Charge Sensitivity: ≈ 10mv / m s-2
- (2) Frequency range: 20Hz-20kHz
- (3) Measuring Range: 0.1-5×10<sup>2</sup>m/s<sup>2</sup>

# 3. High-speed and high precise A / D board

- (1) Sampling Frequency: Up to 200kHz
- (2) Sample Level: 16 bit
- (3) FIFO: 32k byte

(4) Interface:USB

Main Software:1)FFT analysing and testing

- (1) You can set the type and sensitivity of the sensor in the setting window
- (2) A / D sampling rate can be randomly set
- (3) Can separately adjust measuring range of every channel and maximum frequency of anti-aliasing filter
- (4) Can automatically generate longitudinal coordinates according to the type and range of sensor
- (5) Can store and print the measuring result
- (6) Can display both the FFT analytical result and the time domain waveform
- (7) The same software can be used to measure both the noise and the vibration, the user can randomly select testing peak or effective value

# 2)OCT analysing and testing

- (1) Sampling rate: 50kHz / channel
- (2) Dynamic range: 80dB
- (3) Center frequency: 20Hz,25Hz,31.5Hz,40Hz,50Hz,63Hz, 80Hz,100Hz,125Hz,160Hz,200Hz,250Hz,315Hz,

400Hz,500Hz,630Hz,800Hz,1000Hz,1250Hz1600Hz,20000Hz,2500Hz,3150Hz,4000Hz,5000Hz,6300Hz,8000Hz,10kHz、12.5kHz、16kHz

- (4) Parallel 1/30CT analysis
- (5) Can store and print the measuring result
- 3) Architectural acoustics measurement

According to the GBJ75-84"The Construction Noise Regulation", it can measure laboratory measurement of airborne sound insulation of building components, measure spot airborne sound insulation of the outer wall and the outer wall components, measure airborne sound insulation of impact sound of floors and measure on-the-spot air valued according to the GBJ121-88"The Evaluation Criteria of Construction Noise ",and can do reverberation time measurement according to the GBJ76-84"The Reverb

- 4) Sound absorption coefficient measurement
- (1)It can do the laboratory measurement of sound absorption coefficient according to the GBJ47-83" The Sound absorption coefficient measurement Regulation of Reve
- (2) It can do the reverberation time measurement according to the GBJ76-84" The Reverberation Time Measurement Regulation of Living Room"
- (3)You can select the repetitive measuring time from 1 to 18 times when measure the reverberation time. Measuring with 1 / 3 octave, center frequency are 50Hz、63Hz、3150Hz、4000Hz、5000Hz、6300Hz、8000Hz、10000Hz.
- 4) Measuring lower limit frequency can be randomly selected by user among 50Hz, 63Hz, 80Hz, 100Hz
- 5) The maximum frequency can be randomly selected by user among 5000Hz,6300Hz,8000Hz,10000Hz
- 6)It can automatically print the measuring report according to the request of GBJ47-83" The Sound absorption coefficient measurement Regulation of Reverberation Roc
- 7) Measurement range of reverberation time is from 0.2s to 10s
- 8) Can simultaneously calculate T60, T50, T40, T30, T25, The user can define slope of decay curve to calculate the T60
- 9) All measurement results can combine with EXCEL, WORD and other software
- 10)Can display, store and print the time-domain waveform
- 11) Can display, store and print the various time-changing graphics as frequency component changes
- 12) Can display, store and print the frequency characteristic graphics of reverberation time

Head Office :1600 AVENUE DE LORIMIER BUREAU, 384 MONTRÉAL (QUÉBEC) CANADA H2K3W8 USAOffice:128 W SUFFLOK AVE, CENTRAL ISLIP,11722 N Middle east & Africa Office : warehouse 9 /shed 9, Technology park P.O. Box 54806 RAK FZE , UAE

Email Us At:

sales@acculabusa.com middleeast@acculabusa.com

Phone Support:

© Copyright 2014 by ACCULAB\_USA - All rights reserved